

Toyota TUNDRA

 Appliques

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2009 - 2010	8226 8224 8222 8204 8202 8228 8322 8323 8324 8326 8327 8328	Molded Dash Appliques, Bucket Seat 4-pc. Set, Regular Cab	PTS10-34070	8E
2009 - 2010	8354 8352 8350 8346 8345 8344 8343 8342 8341 8340 8339 8335 8331 8252 8250 8246 8245 8244 8243 8242 8241 8240 8239 8216 8215	Molded Dash Appliques, Bucket Seat 6-pc. Set, Double Cab	PTS10-34071	8E
2009 - 2010	8374 8372 8370 8363 8362 8361 8360 8359 8272 8270 8262 8261 8260 8259	Molded Dash Appliques, Bucket Seat, 6-pc. Set, CrewMax, Sequoia 4WD	PTS10-34072	8E
Note: Kit consists of six pieces: dash instrument panel, center console, and four door pieces.				
2007 - 2010	8326 8324 8323 8322	Molded Dash Appliques, Bench Seat 4-pc. Set, Regular Cab	PTS10-34073	8E

	8228			
	8226			
	8224			
	8222			
	8204			
	8202			
	8327			
	8328			
2009 - 2010	8352	Molded Dash Appliques, Bench Seat 6-pc. Set, Double Cab	PTS10-34074	8E
	8350			
	8346			
	8345			
	8344			
	8343			
	8342			
	8341			
	8340			
	8339			
	8335			
	8331			
	8252			
	8250			
	8246			
	8245			
	8244			
	8243			
	8242			
	8241			
	8240			
	8239			
	8216			
	8215			
	8354			
2009 - 2010	8262	Molded Dash Appliques, Bench Seat 6-pc. Set, CrewMax	PTS10-34075	8E
	8261			
	8260			
	8259			
	8270			
	8272			
	8359			
	8360			
	8361			
	8362			
	8363			
	8370			
	8372			
	8374			

Audio/RSE

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2008 - 2010	All	BLU Logic Hands Free System, small button Note: BLU Logic conflicts with: 1) Audio with JBL is a conflict or 2) Audio with Navigation is a conflict(except Scion xB, xD, tC, Corolla, RAV4, and Matrix - Navigation no conflict for these vehicles) or 3)Please confirm that a \"knock-out\" plate is available in the vehicle to mount the switch prior to ordering. or 4) Does not apply to 10MY Camry hybrid vehicles due to lack of switch knock-out locations or 5) conflicts with 09MY Scion xD Release Series 2.0 and 09MY Scion xB Release Series 6.0 as both vehicles come with factory embedded bluetooth	PT923-00090	B3
2008 - 2009	All	Interface kit for iPod Note: Requires audio head unit to be satellite ready. Some premium audio units have embedded XM and conflict with the iPod Interface kit. The 2009 Corolla and 2009 Matrix with Premium Audio (JBL) has embedded XM and conflicts with the iPod Interface. Some base grade audio are not satellite ready. Either iPod or Sat Radio can be installed, not both.	PT545-00082	P5

Compatible iPod Models: iPod mini iPod 4th & 5th generation iPod nano 1st , 2nd & 3rd generation iPod touch iPhone

2007 - 2009	8372 8370 8362 8360 8352 8350 8346 8344 8342 8340 8272 8270 8262 8260 8252 8250 8246 8244 8242 8240 8216	Satellite Radio, XM, Fit Kit	PT546-34070	P7
Note: Applicable to all radios except base radio (radio model AD1803 is not Satellite ready). Requires Tuner Kit 86180-0W030 to complete DIO installation.				
2008 - 2010	All	Satellite Radio, XM, Receiver	86180-0W031	P7
Note: DIO requires ordering specific fit kit and receiver for complete installation. PPO includes both fit kit and receiver. 86180-0W031 required for 08MY Landcruiser. PPO price may differ by vehicle.				
2008 - 2009	All	Satellite Radio, SIRIUS, Receiver	PT545-00080	P2
Note: DIO requires ordering specific fit kit and receiver for complete installation. PPO includes both fit kit and receiver. PPO price may vary by vehicle.				
2008 - 2009	All	Satellite Radio, SIRIUS, Fit Kit	PT545-0C081	P2
Note: DIO requires ordering specific fit kit and receiver for complete installation. PPO includes both fit kit and receiver P/N PT545-00080.				
2009 - 2009	All	Satellite Radio, XM, Fit Kit	PT546-34090	P7
2007 - 2009	All	Satellite Radio, SIRIUS, Receiver	PTS31-53060	P2
Note: Requires separate fit kit to complete installation. Applicable only to vehicles that have JBL satellite ready radio (SAT button) or 6CD Changer (Some Models). This part replaces PTS31-00052. PPO Dealer Cost and PPO MSRP is for entire kit (P2). Highlander application includes hybrid models.				
2004 - 2009	7848 7844 7748 7744	Wireless Headphones	PT900-00031	WH
Note: PPO allows for two wireless headphones, while DIO provides only single unit.				
2004 - 2009	All	Wireless Headphones		WH
Note: PPO allows for two wireless headphones, while DIO provides only single unit.				

Cargo/Storage

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2009 - 2010	8374 8372 8370 8363 8362 8361 8360 8359	Cargo Net, Seat Back Storage Set of 2, CrewMax	PT347-34071	G3

8272
8270
8262
8261
8260
8259

2007 - 2010	All	Cargo Net, Exterior Note: Cannot be installed in conjunction with Bedliner #s PT271-34071, PT271-34073, PT271-34075, PT271-34D71, PT271-34D73, PT271-34D75	PT347-34070	GN
2007 - 2009	8346 8344 8342 8340 8246 8244 8242 8240 8216	Cargo Organizer, Under Seat Storage Note: This can not be installed in vehicles with JBL audio or navigation systems. Hardware Bag Contents: four Retaining clips 58637-0C010, and four Box Floor Knobs 64769-0C010. Additional Service parts that came installed on the assembly: Jack Cover Stopper 64768-04020, Plastic Tapping Screw 90159-40048, Jack Cover Knob 64769-04021, Floor Box #2 Support St 58637-0C010, Floor Box - Black C-Cab 58635-0C010-C0, Floor Lid RH - C-Cab Black 58703-0C010-C0.	PT871-34070	G7
2004 - 2009	All	Emergency Assistance Kit	PT420-00045	7R
2003 - 2009	All	First Aid Kit	PT420-03023	3Z

Door Sill

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2007 - 2009	All	Door Sill Protectors, Front 2-pc., DX Regular Cab Note: PPO includes floor mats. Also offered under PPO CT (with all-weather mats) Dealer cost \$59.00/MSRP \$94.00.	PT747-34073	CF
2007 - 2009	All	Door Sill Protectors, Set of 4, Double Cab Note: PPO cost includes Floor mats. Also in PPO code CT (with All Weather Mats) Dealer cost \$96.00/MSRP \$162.00.	PT747-34074	CF
2007 - 2009	All	Door Sill Protectors, Set of 4, CrewMax Note: PPO cost includes Floor Mats. Also in PPO code CT (with All Weather Mats) Dealer Cost \$128.00/MSRP \$214.00.	PT747-34075	CF

Floor/Cargo Mats

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2007 - 2009	8226 8222 8224 8204 8202 8228 8324 8322 8328 8326	All-Weather Floor Mats, Black 2-pc., Regular Cab Note: PPO CT pricing includes Door Sill Protectors.	PT908-3407B-22	CT
2007 - 2009	8342 8350 8244 8242	All-Weather Floor Mats, Black 4-pc., Double Cab & CrewMax	PT908-3407C-22	CT

8240
8216
8260
8262
8270
8360
8352
8372
8370
8346
8252
8250
8340
8272
8344
8362
8246

Note: PPO CT pricing includes door sill protectors.

2007 - 2010	8202	Carpet Floor Mats, Graphite 2-pc., Regular Cab	PT206-34071-11	CF
	8204			
	8222			
	8224			
	8226			
	8228			
	8322			
	8324			
	8326			
	8328			

Note: PPO CF pricing includes door sill protectors.

2007 - 2010	8202	Carpet Floor Mats, Sand 2-pc., Regular Cab	PT206-34071-43	CF
	8204			
	8222			
	8224			
	8226			
	8228			
	8322			
	8324			
	8326			
	8328			

Note: PPO CF pricing includes door sill protectors.

2007 - 2010	8216	Carpet Floor Mats, Graphite 4-pc., Double Cab & CrewMax	PT206-34072-11	CF
	8240			
	8242			
	8244			
	8246			
	8250			
	8252			
	8260			
	8262			
	8270			
	8272			
	8340			
	8342			
	8344			
	8346			
	8350			
	8352			
	8360			
	8362			
	8370			
	8372			

Note: PPO CF pricing includes door sill protectors.

2007 - 2010	8216	Carpet Floor Mats, Black 4-pc., Double Cab & CrewMax	PT206-34072-12	CF
	8240			
	8242			

8244
8246
8250
8252
8260
8262
8270
8272
8340
8342
8344
8346
8350
8352
8360
8362
8370
8372

Note: PPO CF pricing includes door sill protectors.

2007 - 2010	8216	Carpet Floor Mats, Sand Beige 4-pc., Double Cab & CrewMax	PT206-34072-43	CF
	8240			
	8242			
	8244			
	8246			
	8250			
	8252			
	8260			
	8262			
	8270			
	8272			
	8340			
	8342			
	8344			
	8346			
	8350			
	8352			
	8360			
	8362			
	8370			
	8372			

Note: PPO CF pricing includes door sill protectors.

Front End Accy

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2007 - 2009	8272	Front Skid Plate, Small Engine Under Cover	PT212-34070	S0
	8270			
	8252			
	8250			
	8242			
	8240			
	8228			
	8226			
	8224			
	8222			
	8204			
	8202			
Note: This P/N is applicable to the models listed - Models 8252 and 8250 without Off Road Package (OF), models 8202,8222,8204,8226,8224,8228 without the SR5 Package (SL), and models 8240,8242 with Package (SM). PPO requires TO, DH,or DI for transportation purposes.				
2007 - 2010	8372	Front Skid Plate, Large Engine Under Cover	PT212-34071	S0
	8370			

8362
8360
8352
8350
8346
8344
8342
8340
8328
8326
8324
8322
8262
8260
8252
8250
8246
8244
8242
8240
8228
8226
8224
8222
8216
8204
8202

Note: This P/N is applicable to the models listed: Models 8252 and 8250 with Off Road Package (OF), and models 8202,8222,8204,8226,8224, and 8228 with the SR5 Package (SL). PPO requires TO, DH,or DI for transportation purposes.

2007 - 2009	All	Hood Protector	PT427-34070	HP
-------------	-----	----------------	-------------	----

Misc. Exterior

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2007 - 2009	All	License Plate Frame, Front Bracket	PT413-34070	7J

Misc. Interior

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2009 - 2009	8363	Auto-Dimming Mirror, Homelink/Compass/PRNDL Light	PT374-34070	N1
	8362			
	8361			
	8360			
	8359			
	8346			
	8345			
	8344			
	8343			
	8342			
	8341			
	8340			
	8339			
	8336			
	8335			
	8332			
	8331			
	8328			
	8327			
	8326			
	8324			

- 8323
- 8322
- 8262
- 8261
- 8260
- 8259
- 8246
- 8245
- 8244
- 8243
- 8242
- 8241
- 8240
- 8239
- 8228
- 8226
- 8224
- 8222
- 8216
- 8215
- 8204
- 8202
- 8364

Note: Mirror has Homelink/Compass/PRNDL light. Applicable to Tundra models: DX/SR5/Non-Limited D-Cab. Sequoia models: SR5.

2007 - 2009	8240 8242 8244 8246 8250 8252 8260 8262 8270 8272 8340 8342 8344 8346 8350 8352 8360 8362 8370 8372	Back-up Camera, Back-Up Camera	PT233-34070	5J
-------------	--	--------------------------------	-------------	----

Note: Note: Back-Up Camera Monitor must be ordered along with the Back Up Camera for installation. Bucket Seats (BU) and TO or SO required for V8. V6 requires (BU), Sonar (SO). Not applicable to B-Cab(regular cab) vehicles.

2008 - 2009	All	Back-up Camera, Monitor, Graphite	PT923-00081-11	5J
-------------	-----	-----------------------------------	----------------	----

Note: Monitor must be installed along with Back-Up Camera. PPO pricing reflects both monitor and camera for Tundra. Tundra Application Notes: Not applicable to B-Cab (regular cab) vehicles. Conflicts with factory Navigation. V8 requires Tow package and/or Sonar (SO). V6 must have Sonar (SO).....Exchange Center Info: Back up camera interior monitor has an exchange center for repairs. All other componenets are to be ordered through the PDC. Refer to Warranty Procedures Bulletin, PRO 07-06 for specific details and procedures. Exchange center is: TMI Products, Inc.; 1493 Bentley Drive; Corona, Ca 92879; Phone: 800-624-7960 ext. 149 or 170; Fax: 951-272-4674

2008 - 2009	All	Back-up Camera, Monitor, Beige	PT923-00081-43	5J
-------------	-----	--------------------------------	----------------	----

Note: Monitor must be installed along with Back-Up Camera. PPO pricing reflects both monitor and camera for Tundra. Tundra Application Notes: Not applicable to B-Cab (regular cab) vehicles. Conflicts with factory Navigation. V8 requires Tow package and/or Sonar (SO). V6 must have Sonar (SO).....Exchange Center Info: Back up camera interior monitor has an exchange center for repairs. All other componenets are to be ordered through the PDC. Refer to Warranty Procedures Bulletin, PRO 07-06 for specific details and

procedures. Exchange center is: TMI Products, Inc.; 1493 Bentley Drive; Corona, Ca 92879; Phone: 800-624-7960 ext. 149 or 170; Fax: 951-272-4674

2007 - 2009	All	Back-up Camera, Back-Up Camera Monitor, Graphite Note: Requires PT233-34070 (camera kit) for DIO installation. Not applicable to B-Cab(regular cab) vehicles. Conflicts with factory Navigation. V8 requires Tow package and/or Sonar (SO). V6 must have Sonar (SO). PT923-00081-11 will replace this once stock is depleted. Please continue to order the 0C080 until stock is depleted. Exchange Center Info: Back up camera interior monitor has an exchange center for repairs. All other componenets are to be ordered through the PDC. Refer to Warranty Procedures Bulletin, PRO 07-06 for specific details and procedures. Exchange center is: TMI Products, Inc.; 1493 Bentley Drive; Corona, Ca 92879; Phone: 800-624-7960 ext. 149 or 170; Fax: 951-272-4674	PT923-0C080-11	5J
2007 - 2009	All	Back-up Camera, Back Up Camera Monitor, Biege Note: Requires PT233-34070 (camera kit) for DIO installation. Not applicable to B-Cab(regular cab) vehicles. Conflicts with factory Navigation. V8 requires with Tow package and/or Sonar (SO). V6 must have Sonar (SO). PT923-00081-43 will replace this part once stock is depleted. Please continue to order the 0C080 until stock is depleted. Exchange Center Info: Back up camera interior monitor has an exchange center for repairs. All other componenets are to be ordered through the PDC. Refer to Warranty Procedures Bulletin, PRO 07-06 for specific details and procedures. Exchange center is: TMI Products, Inc.; 1493 Bentley Drive; Corona, Ca 92879; Phone: 800-624-7960 ext. 149 or 170; Fax: 951-272-4674	PT923-0C080-43	5J
2007 - 2009	All	Remote Engine Start, Kit Note: Remote Engine Start kit requires vehicle to have remote keyless entry feature. RKE is standard on all Tundra SR5 and Limited models. Regular cab Tundra base model is the only model with RKE optional. Hood Switch Kit, 08586-0C920 is required for installation on all models without factory alarm hood switch. Tundra Limited models already have factory hood switch.	08586-0C910	V4
2007 - 2009	All	Remote Engine Start, Hood Switch Note: For vehicles without factory alarm. Hood switch is an additional kit required for installation of RES (V4). Not applicable to Limited models.	08586-0C920	V4

Rear Of Vehicle

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2007 - 2009	8372 8352 8362 8346 8342 8328 8324 8272 8252 8262 8246 8242 8228 8224	Exhaust Tip, Kit, 5.7L V8	PTS18-34070	E5
Note: New exhaust tip kit application for new 2007MY Tundra with 5.7L V8 engine.				
2007 - 2009	7710 7711 7720 7721 7722 7726 7728 7736 7738 7742 7744 7748 7810 7811	Exhaust Tip, Exhaust Tip, V6 or 4.7L V8 applications only	PTS18-34090	E5

7818
7820
7821
7822
7826
7828
7836
7838
7842
7844
7848
8202
8204
8216
8222
8226
8240
8244
8250
8260
8270
8322
8326
8340
8344
8350
8360
8370

2007 - 2009	8224	Exhaust Tip, Exhaust Tip, 5.7L V8 Tundra only	PTS18-34091	E5
	8228			
	8242			
	8246			
	8252			
	8262			
	8272			
	8324			
	8328			
	8342			
	8346			
	8352			
	8362			
	8372			

Running Board/Tube Step

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2008 - 2010	8328	Step Board, Brushed Stainless Step Board Kit, Regular	PT212-3407B	RB
	8326	Cab		
	8324			
	8322			
	8228			
	8226			
	8224			
	8222			
	8204			
	8202			
2007 - 2010	8352	Step Board, Brushed Stainless Step Board Kit, Double	PT212-3407C	RB
	8350	Cab		
	8346			
	8344			
	8342			
	8341			
	8340			
	8252			

	8250			
	8246			
	8244			
	8242			
	8240			
	8239			
	8216			
2007 - 2010	8372	Step Board, Brushed Stainless Step Board Kit, CrewMax	PT212-3407D	RB
	8370			
	8362			
	8360			
	8272			
	8270			
	8262			
	8260			
2007 - 2010	8352	Tube Step, Black, Double Cab	PT212-3407C-02	R2
	8350			
	8346			
	8344			
	8342			
	8340			
	8252			
	8250			
	8246			
	8244			
	8242			
	8240			
	8216			
2007 - 2010	8352	Tube Step, Chrome, Double Cab	PT212-3407C-31	R3
	8350			
	8346			
	8344			
	8342			
	8341			
	8340			
	8252			
	8250			
	8246			
	8244			
	8242			
	8240			
	8216			
2007 - 2010	8372	Tube Step, Black, CrewMax	PT212-3407D-02	R2
	8370			
	8362			
	8360			
	8272			
	8270			
	8262			
	8260			
2007 - 2010	8372	Tube Step, Chrome, CrewMax	PT212-3407D-31	R3
	8370			
	8362			
	8360			
	8272			
	8270			
	8262			
	8260			

Shift Knob/Steering Wheel/Pedals

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
------------	--------	-------------	-------------	----------

2007 - 2009	8372	Shift Knob, Anodized Aluminum	PTS22-35072	28
	8370			
	8362			
	8360			
	8352			
	8350			
	8346			
	8344			
	8342			
	8340			
	8324			
	8322			
	8272			
	8270			
	8262			
	8260			
	8252			
	8250			
	8246			
	8244			
	8242			
	8240			
	8224			
	8222			
	8216			
	8202			

Note: Not applicable to vehicles with bench seat (column shift).

2007 - 2009	All	Sport Pedals, Stainless Steel	PTS22-34070	32
-------------	-----	-------------------------------	-------------	----

Towing Accy

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2007 - 2010	All	Towing Accy, Ball Mount Kit for Mexico Market	PT228-34079	
2007 - 2010	8372	Towing Options, 7 Pin Wire Harness	08951-65001	DH
	8370			
	8363			
	8362			
	8361			
	8360			
	8359			
	8352			
	8350			
	8342			
	8341			
	8340			
	8339			
	8331			
	8328			
	8326			
	8324			
	8322			
	8272			
	8270			
	8262			
	8261			
	8260			
	8259			
	8252			
	8250			
	8242			
	8241			
	8240			
	8239			

8228
8226
8224
8222
8216
8215
8204
8202

Note: This towing wire harness kit applies to V8 and also V6 models equipped with steel rear bumper and without factory tow package. Part of PPO DH.

2007 - 2010	8360	Towing Options, Hitch - Resin Bumper, Sport Package	PT228-34073	DI
	8342			
	8340			
	8332			
	8324			
	8322			
	8262			
	8260			
	8242			
	8240			
	8224			
	8222			
	8362			

Note: This hitch is applicable to Tundra's with resin rear bumper, included with Sport Appearance Package (option code: SM). This is a Class III hitch with 5000lb capacity. OEM 4 pin tow wire harness, 82169-0C050 and two bolts, 90119-A0036 are required to complete installation. Service P/N for hitch plug is 51997-0C040.

2007 - 2010	8372	Towing Options, Hitch, Steel Bumper V6/V8	PT228-34074	DH
	8370			
	8363			
	8362			
	8361			
	8360			
	8359			
	8352			
	8350			
	8342			
	8341			
	8340			
	8339			
	8331			
	8328			
	8326			
	8324			
	8322			
	8272			
	8270			
	8262			
	8261			
	8260			
	8259			
	8252			
	8250			
	8242			
	8241			
	8240			
	8239			
	8228			
	8226			
	8224			
	8222			
	8216			
	8215			
	8204			
	8202			

Note: PT228-34074 is for the Tundra with the steel bumper. This is a Class IV hitch with 8000 lb tow capacity. PPO DH includes the 7pin wire harness. DIO will require additional purchase of the 7 pin wire harness 08951-65001. It is not included with hitch kit. Service P/N for hitch plug is PT228-35960-HP.

2007 - 2010	All	Towing Options, Ball Mount	PT228-34077
2007 - 2009	All	Towing Options, 2" Trailer Ball	PT791-00844
2007 - 2010	All	Towing Options, Trailer Ball - 14,000lb 2 5/16" dia, 1 1/4" dia, 2 3/4" long	PT791-00850

TRD

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2007 - 2010	All	Brakes, TRD, Performance Pad, Rear Note: TRD strongly recommends pairing these rear pads with the matching TRD front pads.	PTR09-0C080	
2007 - 2010	All	Brakes, TRD, High Performance Brake Kit Note: Compatible with all Tundra & Sequoia 20" wheels and the TRD 22" Forged Wheel. (This kit will not fit behind 18" wheels). This vehicle is equipped with an 18" spare. If the customer experiences a flat tire on the front axle the customer will have to first install the spare onto the rear axle then replace the flat with the good 20+" rear tire.	PTR09-34070	8S
2007 - 2010	All	Brakes, TRD, Performance Pads, Front Note: Designed to fit the OE calipers	PTR09-34080	
2009 - 2009	8370 8360 8359 8350 8344 8343 8340 8339 8326 8322 8270 8260 8259 8250 8244 8243 8240 8239 8226 8222	Cold Air Intake, TRD, Emissions Legal, 4.7L V8 engine only	PTR03-0C090	
2007 - 2009	8374 8372 8364 8363 8362 8361 8354 8352 8346 8345 8342 8341 8336 8335 8332 8331 8328 8327 8324 8323	Cold Air Intake, TRD, Emissions Legal, 5.7L V8 engine only	PTR03-34090	

	8331			
	8328			
	8327			
	8326			
	8324			
	8323			
	8322			
	8272			
	8270			
	8262			
	8261			
	8260			
	8259			
	8252			
	8362			
	8250			
	8246			
	8245			
	8244			
	8243			
	8242			
	8241			
	8240			
	8239			
	8228			
	8226			
	8224			
	8222			
	8363			
	8364			
	8370			
	8372			
	8374			
2007 - 2009	8216	Filters, TRD, Air, 4.0L V6	PTR05-35060	3F
	8215			
	8204			
	8202			
2008 - 2009	8202	Filters, TRD Air Filter, 4.0L V6 only	PTR43-00070	
	8204			
	8215			
	8216			
2007 - 2010	8370	Filters, TRD, Oil Filter	PTR43-00080	
	8360			
	8359			
	8350			
	8344			
	8343			
	8340			
	8339			
	8326			
	8322			
	8270			
	8250			
	8244			
	8243			
	8240			
	8239			
	8226			
	8222			
	8216			
	8215			
	8204			
	8202			

Note: Packaged in a display ready box.

2009 - 2010	8336	Filters, TRD, Oil Filter	PTR43-00081
	8335		
	8332		
	8331		
	8328		
	8327		
	8324		
	8272		
	8262		
	8261		
	8252		
	8246		
	8245		
	8242		
	8241		
	8228		
	8224		
	8341		
	8342		
	8345		
	8346		
	8352		
	8354		
	8361		
	8362		
	8363		
	8364		
	8372		
	8374		

Note: Packaged in a display ready box.

2000 - 2009	All	Filters, TRD, Kit, Cleaning	PTR05-00000-CL
2000 - 2010	All	Oil Caps, TRD, Japan Note: Fits all Toyota, Lexus, and Scion vehicle engines with screw-on type oil filler cap.	PTR04-12108-02
2000 - 2010	All	Oil Caps, TRD, Forged Aluminum, Screw-on Style	PTR35-00070
2000 - 2010	All	Radiator Caps, TRD, N-Type, 18.5psi Note: TRD radiator cap part number interchanges with OE #16401-62100.	PTR04-00000-03
2007 - 2009	8372 8362 8361 8352 8346 8345 8342 8341 8328 8324 8272 8262 8261 8252 8246 8245 8242 8241 8228 8224	Supercharger, TRD Supercharger 5.7L V8 Main Assembly	PTR29-34070

Note: '09 APPLICATIONS NOT APPLICABLE TO FLEX FUEL MODELS VEHICLE FIT KIT REQUIRED: '07-'08 Tundra = PTR29-34079 '07-'08 Sequoia = PTR29-0C080 '09 Tundra = PTR29-34090 '09 Sequoia = PTR29-0C090 -- Installation time is approximately 9 hours with the first installation likely to take longer. Installation instructions are available on TIS. -- To aid in installation, TRD has developed a hoist mounting bracket that bolts directly onto the supercharger housing lid. The bracket is made from stamped steel and plated to prevent rust (PTR25-34070). -- Engine calibration reflash is available through TIS using your scan tool or TechStream device. No other special tools or adapters are required. -- Warranty is the same

as other TRD powertrain components: 12 months or 12,000 miles or the balance of the 5 year/60,000 mile new car powertrain warranty, whichever is greater, when installed by an authorized Toyota dealer. Superchargers installed by anyone other than an authorized Toyota dealer are warranted for 12 months or 12,000 miles. Specific warranty information is included with the supercharger -- This TRD supercharger is to be sold only as a dealer installed or over-the-counter option after retail sale of the vehicle. This supercharger may not be sold to the customer at the same time as the new vehicle and may not be financed together with the new vehicle.

2007 - 2010	8272 8270 8262 8260 8252 8250 8246 8244 8242 8240 8228 8226 8224 8222 8216 8204 8202	Suspension, TRD, Performance Handling Front Suspension Kit, 4x2	PTR11-34070-01
-------------	--	--	----------------

Note: The TRD Performance Handling Front Suspension Kit (PTR11-34070-01) consists of 2 front TRD tuned shocks, 2 front TRD tuned springs, and the vehicle specific bump stops/hardware kit. The TRD Performance Handling Front Suspension Kit (PTR11-34070-01) is part of complete vehicle TRD Tundra Performance Handling Suspension Kit. In order to complete the kit, the following part numbers ARE REQUIRED: PTR11-34070-01 (Qty:1)- Front Suspension Kit PTR11-34070-02 (Qty:1)- Rear Suspension Kit PTR11-34070-03 (Qty:2)- Rear Leaf Spring

2007 - 2010	8272 8270 8262 8260 8252 8250 8246 8244 8242 8240 8228 8226 8224 8222 8216 8204 8202	Suspension, TRD, Performance Handling Rear Suspension Kit, 4x2	PTR11-34070-02
-------------	--	---	----------------

Note: The TRD Performance Handling Rear Suspension Kit (PTR11-34070-02) consists of 2 rear TRD tuned shocks, 1 TRD rear sway bar and the rear sway bar hardware kit. The TRD Performance Handling Rear Suspension Kit (PTR11-34070-02) is part of complete vehicle TRD Tundra Performance Handling Suspension Kit. In order to complete the kit, the following part numbers ARE REQUIRED: PTR11-34070-01 (Qty:1)- Front Suspension Kit PTR11-34070-02 (Qty:1)- Rear Suspension Kit PTR11-34070-03 (Qty:2)- Rear Leaf Spring

2007 - 2010	8272 8270 8262 8260 8252 8250 8246 8244 8242 8240 8228	Suspension, TRD, Performance Handling Rear Leaf Spring, 4x2	PTR11-34070-03
-------------	--	--	----------------

8226
8224
8222
8216
8204
8202

Note: The TRD Performance Handling Rear Leaf Spring (PTR11-34070-03) consists of 1 rear TRD tuned leaf spring. Two (2) leaf springs are required per vehicle. The TRD Performance Handling Rear Leaf Spring (PTR11-34070-03) is part of complete vehicle TRD Tundra Performance Handling Suspension Kit. In order to complete the kit, the following part numbers ARE REQUIRED: PTR11-34070-01 (Qty:1)- Front Suspension Kit PTR11-34070-02 (Qty:1)- Rear Suspension Kit PTR11-34070-03 (Qty:2)- Rear Leaf Spring

2007 - 2010	All	Suspension, TRD, Tundra Rear Sway Bar, All Note: Tundra TRD Rear Sway Bar is NOT applicable for vehicles equipped with the either of the following Genuine Accessory Hitches: PT228-34073 (Resin Bumper Hitch) PT228-34074 (Steel Bumper Hitch) However, the Rear Sway Bar IS applicable to all vehicles equipped with the Factory Tundra Hitch. Please reference the PANT Bulletin for comparison pictures.	PTR11-34070	HR
2007 - 2009	All	Wheels, TRD, Tire Note: This is the Baja-Proven BFGoodrich All-Terrain T/A LT285/70R17 121/118R M+S Tire for use with the TRD 17" Forged Aluminum Off-Road Wheel (PTR45-34070).		
2009 - 2009	All	Wheels, TRD, Tundra Rock Warrior SE Note: Wheel & Tire Assembly from Dealer Tire, ready to bolt on.		
2007 - 2009	All	Wheels, TRD, Wheel Installation Kit 14mm Note: 14mm TRD Chrome, Spline-Drive, Conical-Seat lug nut vehicle set with captured conical swivel washers. This kit is designed for a 5 lug wheel set. This kit comes with the TRD 17" and the TRD 22" wheels (PTR45-34070 and PTR38-34080) when wheels are installed PPO. This kit includes 16 Spline Drive Lug Nuts, 1 Spline Drive Tool, 4 TRD Wheel Locks with TRD logo laser-etched onto top of each lock, and 1 TRD Wheel Lock Key Tool. Both tools have a 22mm wrench flat and are compatible with the OE vehicle lug wrench. This lugnut set is required and sold separately when TRD wheels are installed DIO. This lugnut set is designed for the 14mm x 1.5 OE thread pitch found on select Toyota vehicles such as 2007~2008 Tundra, 2008 Land Cruiser, and 2008 Sequoia. These lugnuts are NOT designed for use with wheels that have Flat Seat lugholes.	PTR27-60080	
2007 - 2009	All	Wheels, TRD, 22"Forged 5-Spoke Alloy Wheel Note: This wheel P/N supersedes to new wheel box part number PTR38-34080. However, this new part number, PTR38-34080, does NOT come with lugnuts in the wheel box. For one wheel replacement lugnuts, use P/N PTR27-34070. When replacing four wheels order quantity 1 of PTR27-60080, it is a lugnut set for all 4 wheels. Also, must order 1 Owner's Manual Tire Pressure Label, MDC# 00602-35061 from the MDC for each vehicle. FOR TUNDRA: Must also order 1 Tire Pressure Door Jamb Label, MDC# 00602-34080 for each vehicle. FOR SEQUOIA: Must also order 1 Tire Pressure Door Jamb Label, MDC# 00602-0C080 for each vehicle. FOR LAND CRUISER: Must also order 1 Tire Pressure Door Jamb Label, MDC# 00602-60085 for each vehicle. PPO includes Wheels, Tires, Labels, Lugnuts, Wheel Locks, and 20 degree TPMS as needed. ALL OE Styled-Steel Wheels (on Tundras) require TPMS change (42607-0C030 TPMS for 2007 and 42607-0C050 TPMS for 2008 and newer). TPMS Fit Kit 04423-0C170 may also be required.>>>> Tires are Toyo Proxes S/T (285/45R22 114V M + S) PPO P/N is DT001-34070-TO. This wheel uses 14 mm TRD chrome spline-drive conical-seat lugnuts (required and sold separately for DIO) and OE 20 degree TPMS valve stems (not included for DIO). Wheel bolt circle is 5 on 150mm P.C.D. Wheel offset is 50 mm versus 60 mm stock offset. Wheel & Tire PPO includes TRD laser-etched wheel locks.	PTR38-34070	L7
2007 - 2009	All	Wheels, TRD 17" Forged Off-Road Note: Wheel installation kit, PTR27-60080 is required. This kit comes with 16 Spline Drive Conical-Seat 14mm Lug Nuts with captured conical swivel washers, 1 Spline Drive Tool, 4 TRD Wheel Locks with TRD logo laser-etched on top of each lock, and 1 TRD Wheel Lock Tool. Wheels use 20 degree wheel sensor 42607-0C050 and fit kit 04423-0C170. 20 degree sensors are already on 18 inch standard steel wheel and factory 18 and 20 inch alloy wheels. The styled steel wheels have 40 degree sensors and must be changed. Required Door jamb label, owner's manual, and vinyl pouch 00602-06999 are available through the MDC. Must order 1 Owner's Manual Tire Pressure Label, MDC# 00602-35061 from the MDC for each vehicle. FOR TUNDRA: Must also order 1 Tire Pressure Door Jamb Label, MDC# 00602-34085 for each vehicle. FOR SEQUOIA: Must also order 1 Tire Pressure Door Jamb Label, MDC# 00602-0C085 for each vehicle. FOR LAND CRUISER: Must also order 1 Tire Pressure Door Jamb	PTR45-34070	L2

Label, MDC# 00602-60080 for each vehicle. TRD 17" x 8.0" x 50mm Forged Aluminum Off-Road Wheel with Bead Lock Styling. 5 on 150mm P.C.D. 110 mm Center Bore. Uses Conical-Seat Lug nuts 14mm x 1.5.

Truck Bed Accy

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2007 - 2010	All	Truck Bed Accy, Cargo Divider Note: Requires Deck Rail Kit (D9 or DS). The cargo divider allows you to customize your bed size to meet your needs. The cargo divider slides along the bed rails allowing you to separate loads and prevent sliding.	PT767-34070	D2
2007 - 2010	All	Bed Extender	PT329-34073	7T
2007 - 2010	8350 8342 8341 8340 8324 8322 8252 8250 8242 8240 8224 8222 8216 8202 8352	Bed Mat, Regular Bed 6.5	PT580-34070	CJ
2007 - 2010	8346 8344 8328 8326 8246 8244 8228 8226 8204	Bed Mat, Long Bed 8.1	PT580-34070-LB	CJ
2007 - 2010	8372 8370 8362 8360 8272 8270 8262 8260	Bed Mat, Short Bed 5.5	PT580-34070-SB	CJ
2007 - 2010	All	Bed Rug, Short Bed 5.5 Note: This is compatible with bed rails. The top edges need to be trimmed along lines on the back of the rug so rug fits below the rails if needed. The Bed rug conflicts with bed mat and bed liner.	PTS12-34070	
2007 - 2010	All	Bed Rug, Regular Bed 6.5 Note: This is compatible with bed rails. The top edges need to be trimmed along lines on the back of the rug so rug fits below the rails if needed. The Bed rug conflicts with bed mat and bed liner.	PTS12-34071	
2007 - 2010	All	Bed Rug, Long Bed 8.1 Note: This is compatible with bed rails. The top edges need to be trimmed along lines on the back of the rug so rug fits below the rails if needed. The Bed rug conflicts with bed mat and bed liner.	PTS12-34072	
2007 - 2009	8361 8360 8359 8272 8270	Bedliner, 14 or less ordered, Short Bed, For Deck Rail Application	PT271-34070	BL

8262
8261
8260
8259
8372
8370
8362

Note: For order mix of 14 bedliners or less. Applies to vehicle with Deck Rails

2009 - 2009	8362	Bedliner, 14 or less ordered, Short Bed without Rails	PT271-34071	LU
	8361			
	8360			
	8359			
	8262			
	8261			
	8260			
	8259			

Note: Applies to vehicle w/out Deck Rails. For order mix of 14 or less. Cannot be installed in conjunction with Cargo Net #PT347-34070.

2007 - 2009	8339	Bedliner, 14 or less ordered, Regular Bed, For Deck Rail Application	PT271-34072	BL
	8322			
	8252			
	8250			
	8245			
	8243			
	8242			
	8241			
	8240			
	8239			
	8224			
	8222			
	8216			
	8215			
	8202			
	8324			
	8340			
	8341			
	8342			
	8343			
	8345			
	8350			
	8352			

Note: Applies to vehicle with Deck Rails. For order mix of 14 or less.

2007 - 2009	8343	Bedliner, 14 or less ordered, Regular Bed without Rails	PT271-34073	LU
	8342			
	8341			
	8340			
	8339			
	8324			
	8322			
	8245			
	8243			
	8242			
	8241			
	8240			
	8239			
	8224			
	8222			
	8216			
	8215			
	8202			

Note: Applies to vehicle w/out Deck Rails. For order mix of 14 or less. Cannot be installed in conjunction with Cargo Net #PT347-34070.

2007 - 2009	8346	Bedliner, 14 or less ordered, Long Bed, For Deck Rail Application	PT271-34074	BL
	8344			
	8328			

8326
8246
8244
8228
8226
8204

Note: Applies to vehicle with Deck Rails. For order mix of 14 or less.

2007 - 2009	8345 8344 8346 8328 8326 8246 8244 8228 8226 8204	Bedliner, 14 or less ordered, Long Bed without Rails	PT271-34075	LU
-------------	--	--	-------------	----

Note: Applies to vehicle w/out Deck Rails. For order mix of 14 or less. Cannot be installed in conjunction with Cargo Net #PT347-34070.

2007 - 2009	8360 8359 8272 8270 8262 8261 8260 8259 8361 8362 8370 8372	Bedliner, For orders of 40 units or more, Short Bed, For Deck Rail Application	PT271-34D70	BL
-------------	--	--	-------------	----

Note: Applies to vehicle with Deck Rails. Order mix of 40 or more.

2007 - 2009	8359 8262 8261 8260 8360 8361 8362	Bedliner, For Orders of 40 Units or More, Short Bed without Rails	PT271-34D71	LU
-------------	--	---	-------------	----

Note: Applies to vehicle w/out Deck Rails. Order mix of 40 or more. Cannot be installed in conjunction with Cargo Net #PT347-34070.

2007 - 2009	8250 8245 8243 8242 8241 8240 8239 8224 8222 8216 8215 8202 8252 8322 8324 8339 8340 8341 8342 8343 8345 8350 8352	Bedliner, For Orders of 40 Units or More, Regular Bed, For Deck Rail Application	PT271-34D72	BL
-------------	--	--	-------------	----

Note: Applies to vehicle with Deck Rails. Order mix of 40 ordered or more.

2008 - 2009	8243	Bedliner, For Orders of 40 Units or More, Regular Bed without Rails	PT271-34D73	LU
	8242			
	8241			
	8240			
	8239			
	8224			
	8222			
	8216			
	8215			
	8202			
	8245			
	8322			
	8324			
	8339			
	8340			
	8341			
	8342			
	8343			
	8345			

Note: Applies to vehicle w/out Deck Rails. Order mix of 40 or more. Cannot be installed in conjunction with Cargo Net #PT347-34070.

2007 - 2009	8346	Bedliner, For orders of 40 units or more., Long Bed, For Deck Rail Application	PT271-34D74	BL
	8344			
	8328			
	8326			
	8246			
	8244			
	8228			
	8226			
	8204			

Note: Applies to vehicle with Deck Rails. Order mix of 40 or more.

2007 - 2009	8346	Bedliner, For orders of 40 units or more, Long Bed without Rails	PT271-34D75	LU
	8344			
	8328			
	8326			
	8246			
	8244			
	8228			
	8226			
	8204			

Note: Applies to vehicle w/out Deck Rails. Order mix of 40 or more. Cannot be installed in conjunction with Cargo Net #PT347-34070.

2007 - 2009	8360	Bedliner, 15-39 ordered, Short Bed, for Deck Rail Application	PT271-34E70	BL
	8359			
	8272			
	8270			
	8262			
	8261			
	8260			
	8259			
	8361			
	8362			
	8370			
	8372			

Note: Applies to vehicle with Deck Rails. For order mix of 15-39 bedliners ordered.

2008 - 2009	8362	Bedliner, 15-39 ordered, Short Bed, without Deck Rails	PT271-34E71	LU
	8361			
	8360			
	8359			
	8262			
	8261			
	8260			
	8259			

Note: Applies to vehicle w/out Deck Rails. For order mix of 15-39 bedliners ordered.

2007 - 2009	8322	Bedliner, 15-39 ordered, Regular Bed, For Deck Rail Application	PT271-34E72	BL
	8252			
	8250			
	8245			
	8243			
	8242			
	8241			
	8240			
	8239			
	8224			
	8222			
	8216			
	8215			
	8202			
	8324			
	8339			
	8340			
	8341			
	8342			
	8343			
	8345			
	8350			
	8352			

Note: Applies to vehicle with Deck Rails. For order mix of 15-39 bedliners ordered.

2008 - 2009	8243	Bedliner, 15-39 ordered, Regular Bed, without Deck Rail	PT271-34E73	LU
	8242			
	8241			
	8240			
	8239			
	8224			
	8222			
	8216			
	8215			
	8202			
	8245			
	8322			
	8324			
	8339			
	8340			
	8341			
	8342			
	8343			
	8345			

Note: Applies to vehicle w/out Deck Rails. For order mix of 15-39 bedliners ordered.

2007 - 2009	8346	Bedliner, 15-39 ordered, Long Bed, For Deck Rail Application	PT271-34E74	BL
	8344			
	8328			
	8326			
	8246			
	8244			
	8228			
	8226			
	8204			

Note: Applies to vehicle with Deck Rails. For order mix of 15-39 bedliners ordered.

2007 - 2009	8204	Bedliner, 15-39 ordered, Long Bed, without Deck Rail	PT271-34E75	LU
	8226			
	8228			
	8244			
	8246			
	8326			
	8328			
	8344			
	8346			

Note: Applies to vehicle w/out Deck Rails. For order mix of 15-39 bedliners ordered.

2007 - 2010	8354 8352 8350 8346 8344 8342 8340 8335 8332 8331 8328 8327 8326 8324 8323 8322 8272 8270 8262 8260 8252 8250 8246 8244 8242 8240 8228 8226 8224 8222 8216 8204 8202 8360 8362 8363 8364 8370 8372 8374	Mini-Tie Down, with Hook (Set of 2)	PT278-35075	RT
-------------	--	-------------------------------------	-------------	----

Note: Requires deck rail kit (R9 or DS), Limited Models. Also applies to Tacoma.

2007 - 2009	8262 8360 8272 8270 8372 8370 8362 8260	Tonneau Cover, Short Bed, Slate Metallic 1F9	PT271-34070-01	BT
-------------	--	--	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262 8360 8272 8270 8372 8370 8362 8260	Tonneau Cover, Short Bed, Black 202	PT271-34070-02	BT
-------------	--	-------------------------------------	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already

has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262 8260 8360 8272 8270 8372 8370 8362	Tonneau Cover, Short Bed, Salsa Red Pearl 3Q3	PT271-34070-03	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8270 8262 8360 8272 8372 8370 8362 8260	Tonneau Cover, Short Bed, Desert Sand Mica 4Q2	PT271-34070-04	BT
-------------	--	--	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262 8260 8360 8272 8270 8372 8370 8362	Tonneau Cover, Short Bed, Timberland Mica 6T8	PT271-34070-06	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262 8372 8260 8360 8272 8270 8370 8362	Tonneau Cover, Short Bed, Nautical Blue Metallic 8S6	PT271-34070-08	BT
-------------	--	--	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8270 8262 8362 8360 8272 8372 8370 8260	Tonneau Cover, Short Bed, Super White 040	PT271-34070-10	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262 8270 8360 8272 8372 8370 8362 8260	Tonneau Cover, Short Bed, Silver Sky Metallic 1D6	PT271-34070-11	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262 8260 8360 8272 8270 8372 8370 8362	Tonneau Cover, Short Bed, Radiant Red 3L5	PT271-34070-13	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262 8260 8360 8272 8270 8372 8370 8362	Tonneau Cover, Short Bed, Bronze M.M. 4T3	PT271-34070-14	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262 8260 8360 8272 8270	Tonneau Cover, Short Bed, Blue Streak Metallic 8T7	PT271-34070-18	BT
-------------	--------------------------------------	--	----------------	----

8372
8370
8362

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8350 8222 8242 8324 8352 8224 8250 8340 8216 8252 8342 8240 8202 8322	Tonneau Cover, Standard Bed, Slate Metallic 1F9	PT271-34071-01	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8222 8242 8324 8224 8352 8250 8340 8216 8252 8342 8240 8202 8322 8350	Tonneau Cover, Standard Bed, Black 202	PT271-34071-02	BT
-------------	--	--	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8324 8352 8224 8250 8340 8216 8252 8342 8202 8240 8322 8350	Tonneau Cover, Standard Bed, Salsa Red Pearl 3Q3	PT271-34071-03	BT
-------------	--	--	----------------	----

8222
8242

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352 8224 8250 8340 8216 8252 8342 8202 8240 8322 8350 8222 8242 8324	Tonneau Cover, Standard Bed, Desert Sand Mica 4Q2	PT271-34071-04	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8250 8340 8216 8252 8342 8202 8240 8322 8350 8222 8242 8324 8352 8224	Tonneau Cover, Standard Bed, Timberland Mica 6T8	PT271-34071-06	BT
-------------	--	--	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8340 8216 8252 8342 8202 8240 8322 8350 8222 8324 8242 8352 8224 8250	Tonneau Cover, Standard Bed, Nautical Blue Metallic 8S6	PT271-34071-08	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8240 8322 8222 8350 8242 8324 8352 8224 8250 8340 8216 8252 8342 8202	Tonneau Cover, Standard Bed, Super White 040	PT271-34071-10	BT
-------------	--	--	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8322 8350 8222 8242 8324 8352 8224 8250 8340 8216 8252 8342 8240 8202	Tonneau Cover, Standard Bed, Silver Sky Metallic 1D6	PT271-34071-11	BT
-------------	--	--	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8242 8324 8224 8352 8250 8340 8216 8252 8342 8202 8240 8322 8350 8222	Tonneau Cover, Standard Bed, Radiant Red 3L5	PT271-34071-13	BT
-------------	--	--	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already

has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8224 8250 8340 8216 8252 8342 8202 8240 8322 8350 8222 8242 8324 8352	Tonneau Cover, Standard Bed, Bronze M.M. 4T3	PT271-34071-14	BT
-------------	--	--	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8216 8252 8202 8342 8240 8322 8222 8350 8242 8324 8352 8224 8250 8340	Tonneau Cover, Standard Bed, Blue Streak Metallic 8T7	PT271-34071-18	BT
-------------	--	---	----------------	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8270 8362 8262 8360 8260 8272 8370 8372	Tonneau Cover, Short Bed, Slate Metallic 1F9		BT
-------------	--	--	--	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262 8362 8360	Tonneau Cover, Short Bed, Black 202		BT
-------------	----------------------	-------------------------------------	--	----

8260
8272
8270
8370
8372

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8260 8360 8272 8270 8262 8362 8370 8372	Tonneau Cover, Short Bed, Salsa Red Pearl 3Q3	BT
-------------	--	---	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8272 8270 8362 8262 8260 8360 8370 8372	Tonneau Cover, Short Bed, Desert Sand Mica 4Q2	BT
-------------	--	--	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8272 8270 8262 8260 8360 8362 8370 8372	Tonneau Cover, Short Bed, Timberland Mica 6T8	BT
-------------	--	---	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8272 8270 8262 8360 8260 8362 8370 8372	Tonneau Cover, Short Bed, Nautical Blue Metallic 8S6	BT
-------------	--	--	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8272	Tonneau Cover, Short Bed, Super White 040	BT
	8270		
	8362		
	8262		
	8260		
	8360		
	8370		
	8372		

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8270	Tonneau Cover, Short Bed, Silver Sky Metallic 1D6	BT
	8362		
	8262		
	8360		
	8260		
	8272		
	8370		
	8372		

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8360	Tonneau Cover, Short Bed, Radiant Red 3L5	BT
	8260		
	8272		
	8270		
	8262		
	8362		
	8370		
	8372		

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8262	Tonneau Cover, Short Bed, Pyrite Mica 4T3	BT
	8362		
	8360		
	8260		
	8272		
	8270		
	8370		
	8372		

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added,

please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8260 8262 8270 8272 8360 8362 8370 8372	Tonneau Cover, Short Bed, Blue Streak Metallic 8T7	BT
-------------	--	--	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352 8350 8342 8340 8324 8252 8250 8242 8240 8224 8222 8216 8202	Tonneau Cover, Standard Bed, Slate Metallic 1F9	BT
-------------	--	---	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352 8350 8342 8340 8324 8252 8250 8242 8240 8224 8222 8216 8202	Tonneau Cover, Standard Bed, Black 202	BT
-------------	--	--	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352 8350 8342 8340 8324 8252 8250 8242	Tonneau Cover, Standard Bed, 3Q3 Salsa Red Pearl	BT
-------------	--	--	----

8240
8224
8222
8216
8202

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352 8350 8342 8340 8324 8252 8250 8242 8240 8224 8222 8216 8202	Tonneau Cover, Standard Bed, 4Q2 Desert Sand Mica	BT
-------------	--	---	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352 8350 8342 8340 8324 8252 8250 8242 8240 8224 8222 8216 8202	Tonneau Cover, Standard Bed, 6T8 Timberland Mica	BT
-------------	--	--	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352 8350 8342 8340 8324 8252 8250 8242 8240 8224 8222 8216 8202	Tonneau Cover, Standard Bed, 8S6 Nautical Blue Metallic	BT
-------------	--	---	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352	Tonneau Cover, Standard Bed, Super White 040	BT
	8350		
	8342		
	8340		
	8324		
	8252		
	8250		
	8242		
	8240		
	8224		
	8222		
	8216		
	8202		

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352	Tonneau Cover, Standard Bed, Silver Sky Metallic 1D6	BT
	8350		
	8342		
	8340		
	8324		
	8252		
	8250		
	8242		
	8240		
	8224		
	8222		
	8216		
	8202		

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352	Tonneau Cover, Standard Bed, Radiant Red 3L5	BT
	8350		
	8342		
	8340		
	8324		
	8252		
	8250		
	8242		
	8240		
	8224		
	8222		
	8216		
	8202		

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added,

please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352 8350 8342 8340 8324 8252 8250 8242 8240 8224 8222 8216 8202	Tonneau Cover, Standard Bed, 4T3 Pyrite Mica	BT
-------------	--	--	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2009	8352 8350 8342 8340 8324 8252 8250 8242 8240 8224 8222 8216 8202	Tonneau Cover, Standard Bed, 8T7 Blue Streak Metallic	BT
-------------	--	---	----

Note: Note for Tonneau Cover Application on Non-Deck Rail System equipped Tundra. When installing a Tonneau Cover on a Tundra without the Deck Rail System but the vehicle already has a Toyota Bedliner some modification to the Bedliner is necessary. Please refer to the instructions on TIS for details on this modification. When installing a Tonneau Cover on a Tundra that does not already have a Toyota Bedliner but a Bedliner is going to be added, please use the following PN's: Short Bed Bedliner PT271-34070, PT271-34E70 or PT271-34D70. Standard Bed Bedliner PT271-34072, PT271-34E72 or PT271-34D72.

2007 - 2010	8352 8350 8346 8344 8342 8340 8335 8332 8331 8328 8327 8326 8324 8323 8322 8272 8270 8262 8260 8252 8250 8246 8244 8242	Truck Bed Accy, Bed Cleat Kit, Single, Requires DS or R9, Limited Models	PT278-34070
-------------	--	--	-------------

8240
8228
8226
8224
8222
8216
8204
8202
8354
8360
8362
8363
8364
8370
8372
8374

2007 - 2010	8363 8362 8360 8262 8260 8374 8364	Truck Bed Accy, Deck Rail Kit, Short Bed, 5.5 ft. Bed	PT278-34071	R9
-------------	--	---	-------------	----

Note: Deck rail kit fits Tundra with or without Toyota Bedliner. Kit includes 4 Deck Rail cleats. When installing the Deck Rail System with a Toyota Bedliner a Z Bracket is required to mount the Deck Rail onto the Header Board. The Z Bracket is included in the hardware kit with every Toyota Bedliner made to fit with the Deck Rail System. For Toyota Bedliners already installed or Toyota Bedliners that were ordered to fit without the Deck Rail System, a new Hardware Kit that includes the Z Bracket has to be ordered separately. The Hardware Kit PT271-34070-HW can be ordered via Daily Order or contact 1-800-OELINER to order as the Hardware Kit is Direct Shipped from OELINER regardless of which ordering method. It is not shipped overnight with stock orders.

2007 - 2010	8354 8342 8340 8332 8331 8324 8323 8322 8242 8240 8224 8222 8216 8202	Truck Bed Accy, Deck Rail Kit, Regular Bed, 6.5 ft. Bed	PT278-34072	R9
-------------	--	---	-------------	----

Note: Deck rail kit fits Tundra with or without Toyota Bedliner. Kit includes 4 Deck Rail cleats. When installing the Deck Rail System with a Toyota Bedliner a "Z" Bracket which mounts to the Deck Rail on the Header Board is required. The "Z" Bracket is included in the hardware kit with every Toyota Bedliner made to fit with the Deck Rail System. For Toyota Bedliners already installed or Toyota Bedliners that were ordered to fit without the Deck Rail System, a new Hardware Kit that includes the "Z" Bracket has to be ordered. The Hardware Kit PT271-34070-HW can be ordered via Daily Order or contact 1-800-OELINER to order as the Hardware Kit is Direct Shipped from OELINER regardless of which ordering method. It is not shipped overnight with stock orders.

2007 - 2010	8344 8335 8328 8327 8326 8246 8244 8228 8226 8204 8346	Truck Bed Accy, Deck Rail Kit, Long Bed, 8.1 ft. Bed	PT278-34073	R9
-------------	--	--	-------------	----

Note: Deck rail kit fits Tundra with or without Toyota Bedliner. Kit includes 4 Deck Rail cleats. When installing the Deck Rail System with a Toyota Bedliner a "Z" Bracket which mounts to the Deck Rail on the Header Board is required. The "Z" Bracket is included in the hardware kit with every Toyota Bedliner made to fit with the Deck Rail System. For Toyota Bedliners already installed or Toyota Bedliners that were ordered to fit without the Deck Rail System, a new Hardware Kit that includes the "Z" Bracket has to be ordered. The Hardware Kit PT271-34070-HW can be ordered via Daily Order or contact 1-800-OELINER to order as the Hardware Kit is Direct Shipped from OELINER regardless of which ordering method. It is not shipped overnight with stock orders.

2007 - 2010	8352	Truck Bed Accy, Locking Fork Mount Bike Rack, Limited	PTS08-34070	BK
	8350	Models		
	8346			
	8344			
	8342			
	8340			
	8335			
	8332			
	8331			
	8328			
	8327			
	8326			
	8324			
	8323			
	8322			
	8272			
	8270			
	8262			
	8260			
	8252			
	8250			
	8246			
	8244			
	8242			
	8240			
	8228			
	8226			
	8224			
	8222			
	8216			
	8204			
	8202			
	8354			
	8360			
	8362			
	8363			
	8364			
	8370			
	8372			
	8374			

Note: Requires deck rail kit (R9 or DS).

2007 - 2010	All	Truck Bed Accy, Bed Step	PT392-34090	8Q
		Note: Please note this accessory only fits vehicles using the factory hitch. Conflicts with vehicles having the accessory hitch.		

Vehicle Intrusion Protection

MODEL YEAR	MODELS	DESCRIPTION	PART NUMBER	PPO Code
2007 - 2010	8372	VIP Security System, RS3200Plus and GBS, Requires	08586-0C890	
	8370	Keyless Entry		
	8362			
	8360			
	8352			
	8350			

- 8228
- 8240
- 8242
- 8244
- 8246
- 8260
- 8262
- 8322
- 8324
- 8326
- 8328
- 8340
- 8342
- 8344
- 8346
- 8360
- 8362

Note: Replaces p/n PT533-34070. PPO: For vehicles with steel and styled steel wheels. PPO includes 4 tires (order thru Dealer Tire), 4 wheels, 4 TPMS, and 4 sets of lug nuts PT533-3407B (1 set equals 5), 1 B-Pillar label 00107-00399 (MDC Order). DIO: 5 -Spoke Styled Steel wheels require TPMS change (42607-0C050 TPMS/04423-0C170 Fit Kit as required); steel wheel reuse factory TPMS; alloy wheel reuse factory TPMS. Recommended tire size P275/55R20 is noted on the installation instructions. Launch of this product has been moved to a date to be determined. Should order PT533-34070 when PT533-34071 is not available.

2007 - 2010	8362	Alloy Wheels, 5-pc., Bulk Lug Nuts Set	PT533-3407B	SS
	8360			
	8346			
	8344			
	8342			
	8340			
	8328			
	8326			
	8324			
	8322			
	8262			
	8260			
	8246			
	8244			
	8242			
	8240			
	8228			
	8226			
	8224			
	8222			
	8216			
	8204			
	8202			

Note: Included in PPO SS. One piece equals a set of 5 lug nuts. Use with wheel PT533-34070.

2009 - 2010	All	Alloy Wheels, 20" Carve Tire, Special Edition	DT001-34072	
2009 - 2010	All	Alloy Wheels, Carve wheel assembly, Special edition		
2009 - 2010	All	Alloy Wheels, 20" Center Cap (Machined Star 5-Spoke)	PT385-34090-CC	
2009 - 2010	All	Alloy Wheels, 20" Machined Star 5-Spoke	PT758-34090	WB
		Note: DIO Installation: PT758-34090 single Machined Star 5-Spoke, PT385-34090-CC single Center Cap. If vehicle is equipped with a factory styled steel wheels, it will require a new TPMS kit (42607-0C050) and fit kit (04423-0C170). If vehicle is equipped with a factory non-styled steel wheel or alloy wheel, reuse factory TPMS. Recommended tire size P275/55R20 is noted on the installation instructions.		
2007 - 2010	All	Spare Tire Lock	PT276-34070	WI
2007 - 2010	All	Wheel Locks, Clear Chrome	PT276-60070	WL
2007 - 2010	All	Wheel Locks, Clear Chrome		WL